

Chair Back Height Tester

This tester is used to measure height of chair back.

Model	QRCBH-210
-------	-----------



Chair Seat Tester

This tester is used to measure height of chair seat.

Model	QRCS-211
-------	----------



Chair Center Test

This tester is used to measure center and position of chair seat and back.

Model	QRCS-211
-------	----------



Chair Center Post Depth Tester

This tester is used to measure center and position of chair seat and back.

Model	QRCCPD-213
-------	------------

